

NOSE TRIMMER
E650E

Please carefully read the safety instructions before using the product.

Preparation

- Always inspect the appliance before use for noticeable signs of damage. Do not use if damaged as injury may occur.
- Ensure trimmer head is free from hair and debris (refer to Cleaning & Maintenance section for further information).

To Operate the Trimmer

- To insert a battery, remove the base of the device by turning it to the left, so that mark (I) lines up with mark (). Then pull the base of the device downwards (Fig. 1).
- Insert one AA alkaline battery, positive terminal up. (If you are not going to use the device for long periods, or if the battery is flat, remove the battery from the device. This will increase the trimmer's working life.)
- After inserting the battery, put the base of the device firmly back in position.
- Turn the device on by turning the base of the device to the right to line up the two marks (I) (Fig. 2).

To get rid of unwanted nasal or ear hairs,

Gently insert the rotary cutting head into the nostril or ear to cut the hair.

Inserting and removing the cutting head


- Turn the device to the «off» position by turning the base of the device to the left so that mark (I) lines up with mark (O) (Fig. 3).
- Gently place the cutting head on the device, then lock in position by turning the cutting head to the left so that the two marks line up (I) (Fig. 4).
- Remove the cutting head of the device by turning it to the right, to line up mark (I) with mark (). Then pull the head of the device upwards (Fig. 5)

CLEANING & MAINTENANCE

- Turn the device to the «off» position (Fig. 3).
- Remove the head of the device by turning it to the right to line up mark (I) with mark ().
- Then pull the head of the device upwards (Fig. 5) Remove any build-up of hairs on the head by blowing on them or using a small cleaning brush. You can also rinse the head of the device under running water (Fig. 6). However, the handle must not come into contact with water. Remove the cutting head of the device to rinse it under water.
- Ensure the head is completely dry before replacing on the device and turn it to the left until the marks are lined up.
- Do not use the device in the shower or bath.

Made in China
Fabriqué en Chine

E650E



BABYLISS SARL
99 avenue Aristide Briand
92120 Montrouge
France

www.babyliss.com

FAC / 2019 / 03

